

## ORCA 3D SOFTWARE INSTALLATION GUIDE

1. Download from here: <https://orca3d.com/pages/version2>

### The **NETWORK CLIENT INSTALLATION**

2. Run the .exe file and follow the steps, it may ask you to install a .NET framework, accept
3. Then run Rhinoceros and a window will appear with 3 options:
4. Click the **Network client** option and insert the number:

192.168.1.54:10589